


OPERATION GUIDE



SAFETY NOTE:

To prevent unauthorized use of this product, unplug the control cord from the base of the hand control and store in a secure location. To resume operation, simply plug the control cord into the hand control.

IMPORTANT:

Read advisory information in the owners manual carefully before using this product. The potential for electrical shock exists if electrical components are not installed or operated properly.